

Sentry

Code Hopping 1 Channel programming instructions

SEN/H/T1

The transmitters are pre-coded at the factory and ready to be individually programmed into the receiver.

- 1) Select latch or pulse before connecting power
- 2) Connect as shown:
Connect NEG and COM for systems requiring negative trigger
Connect 12/24V and COM for systems requiring positive trigger
- 3) Press and release program button (only once)
- 4) LED will flash for 0.2 seconds
- 5) Operate transmitter to be learnt at least 2 metres away
- 6) LED will flash 3 times
- 7) Repeat the above 2 sequences until all transmitters have been learnt, if using less than 32 transmitters the sequence must still be repeated to simulate the learning of 32 transmitters.
LED will flash twice
- 8)
 - a) For pulse or latch press and release program button, LED will flash once to indicate exit from program mode.

Or

- b) For time delay press and hold down program button for desired relay 'on' time (maximum 25 seconds). Release program button, LED will flash once to indicate exit from program mode.
- Operate transmitters as required.

