

Sentry

Binary & French Rolling Code 1 Channel

programming instructions

SEN/B/T1 & SEN/R/T1

Code transmitters all to same code using the dip switches in the transmitter. DO NOT use 'All on' or All off'

- 1) Select latch or pulse before connecting power
 - 2) Connect power to receiver as per P.C board
 - 3) Lightly press and release program button (only once)
 - 4) LED will flash once
 - 5) Operate transmitter to be learnt at least 1 metre away
 - 6) LED will flash twice
 - 7)
 - a) For pulse or latch press and release program button, LED will flash once to indicate exit from program mode.
- Or ONLY IF YOU HAVE THE TIME DELAY OPTION
- b) For time delay press and hold down program button for desired relay 'on' time (maximum 25 seconds). Release program button, LED will flash once to indicate exit from program mode.
- Operate transmitters as required.

